

a: drive the flexible guide post in line with the guardrail posts, or b: install the shorter flexible guide post on the guardrail post.

NOTES:

2. Guardrail-mounted quide posts shall be fastened to the quardrail post with two 20d galvanized nails, or two 50 x 10 lag screws with washers, as near to the centerline of the post as possible. Also acceptable is any approved method submitted by the quide post manufacturer.

3. Guide posts shall be 0.6 m from the edge of shoulder unless otherwise

4. Flexible tubular posts shall have a band of reflective sheeting near

1. The contractor shall either:

the tops of the post, at least 200 wide, around the entire post. See Notes for attachment -÷75 Ε

specified.

Approximately 1.2 ane apove पामाङ्माङमाङमाङमाङमाङमाङमाङमाङ माङ्माङमाङ FLEXIBLE GUIDE POST

(GUARDRAIL)

(Use only with wood quardrail posts)

STATE DESIGN ENGINEER APPROVED .

ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE NOTED. GUIDE POSTS

WASHINGTON STATE DEPARTMENT OF TRANSPORTATION OLYMPIA, WASHINGTON

STANDARD PLAN H-1